

It's **EASY** to install a high efficiency showerhead and save on your water **AND** energy bills!



1. Hold the pipe coming out of the wall and carefully twist off the old showerhead.



2. Clean the threads of the pipe.



3. Wrap Teflon tape around the pipe threads in a clockwise direction.



4. Line up the thread of the new showerhead and screw on in a clockwise direction until snug.